# INSTRUCTION MANUAL

### **HIGHBAY 200W**

9992051

DIRHB200LEDDL



## **SPECIFICATIONS**

Rated Power 200W

Input Votage 240VAC, 50Hz

**DirectWholesale** 

 Power Factor
 0.9

 CRI (Ra)
 >80

 Lumen Output
 24000Lm

 Colour Temperature
 5000K

 Ingress Protection Rating
 IP65

 Beam Angle
 110°

Product Dimensions 430x157mm
Warranty 3 years





## **INSTALLATION INSTRUCTIONS**

#### Installation Instructions using eye bolt:

- Ensure that the power has been isolated before attempting installation
- Ensure the desired location is suitable and clear of all obstruction
- Install a suitable standard three pin socket (240V 10A) adjacent to the mounting point

**Note:** Highbay light has a 2m flex and plug provided

- 4. Ensure mounting hook is suitable to carry the weight of the Highbay light
- 5. Using all appropriate safety measures, hang Highbay light on mounting hook and ensure it is secure
- 6. Plug Highbay light into 3 pin socket
- Energise and test luminaire

#### Installation Instructions using wall bracket:

- Ensure that the power has been isolated before attempting installation
- Ensure the desired location is suitable and clear of all obstruction
- Install a suitable standard three pin socket (240V 10A) adjacent to the mounting point
  - **Note:** Highbay light has a 2m flex and plug provided Use the wall bracket to mark the hole centres for
- Use the wall bracket to mark the hole centres for fixing. Drill holes suitable to accept wall plugs
- 5. Insert wall plugs
- 6. Fix Bracket to wall using appropriate screws
- 7. Fit the luminaire to the wall bracket
- Terminate supply wiring to the luminaire in an approved manner. Ensure that IP rating is maintained
- 9. Check seals, gaskets and cable gland operation



before testing the luminaire

10. Energise and test luminaire

#### WARNING: RISK OF ELECTRIC SHOCK

This product shall be installed by a licenced electrician in compliance with the requirements set out in AS/NZS 3000 (current edition) and other relevant Standards and Regulations pertaining to the installation.

This product must only be used for the purpose outlined in this instruction manual.

Failure to follow these instructions may result in serious injury or death.

Prior to installing this product, check whether the product has been damaged during transport. Do not operate/ install the product if damaged in any way. Return complete product to the place of purchase for inspection, repair or replacement.

## **WARRANTY**



#### WARRANTY PROCESS

- This product is guaranteed against faulty workmanship and materials for a period of three (3) years or 20,000
  hours, whichever comes first, from the date of installation
- Direct Wholesale will, at its discretion, repair, replace, or offer a refund for any defective product
- This warranty is expressly subject to the Direct Wholesale product being installed, wired, tested, operated and
  used in accordance with our instructions and specifications
- · Any alterations or modifications made to the product without our permission will void the warranty
- Direct Wholesale will not be responsible for the cost of retrieving, removing, reinstalling, transporting (including return of the defective product to us) or re-testing a product

#### **CLAIM PROCESS**

- You shall provide Direct Wholesale with adequate particulars of the defect within 28 days of the fault occurring
- Warranty claims, including all defect particulars and proof of purchase, shall be submitted to the following email address for consideration: admin@directwholesale.com.au
- Returned products must be securely packed and labelled for proper processing

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.