
:hager

User intructions

To the customers for safety switches / circuit breaker combination



Tripping

If tripping occurs, unplug all appliances. Reset switch. Individually plug in each appliance until the safety switch trips to determine the faulty appliance:

- 1- If the safety switch does not trip with individual appliances, then the circuit may be overloaded.
- 2- If the safety switch trips with no appliances connected, the installation cabling may be damaged. Consult an electrician.

INSTALLED BY:

Hager B&R Pty Ltd
Unit 1/170 Power Street Glendenning NSW 2761 AUSTRALIA
Tel: (61) 2-8867 7600 www.hagerbr.com.au

6A1400.a